		INITIAL SERVICE PERIOD	REGULAR SERVICE PERIOD Perform at every indicated month or mileage interval whichever occurs first.			
MAINTENANCE SCHEDULE	Month	-	1	3	6	12
	Mile	500	500	1,500	3,000	6,000
Engine Oil		R		R		
Engine Oil Filter Element		R			R	
Engine Oil Filter Screen						С
Spark Plugs					I	
* Contact Breaker Points		I			I	
*Ignition Timing		I			Ι	
*Valve Tappet Clearance		I			Ι	
*Cam Chain Tension		I			Ι	
Air Filter Elements		(Service more frequently if operated in dusty areas.)			С	R
Air Filter Breather Element		· ·		C+	С	
*Carburettors		I			I	
Throttle Operation		I			I	
*Fuel Filter Screen					С	
Fuel Lines					I	
*Clutch		I			Ι	
Drive Chain		**I&L	I&L			
Brake Fluid Level		I			Ι	
*Brake Fluid			R (24 months or 12,000 miles)			iles)
*Brake Shoes/Pads					Ι	
Brake Control Linkage		I			Ι	
*Wheel Rims and Spokes		I			I	
Tyres		Ι	I+		Ι	
Front Fork Oil		***R				R
Front and Rear Suspension		I			I	
Rear Fork Bushing					I&L	
*Steering Head Bearings						Ι
*Side Stand					Ι	
Battery		Ι		Ι		
Lighting Equipment		I	I+		Ι	
Nuts, Bolts (Tighten)		Ι			Ι	

Honda CB400F, F1, F2 Models 1974 to 1979

I – Inspect, clean, adjust or replace if necessary $\,$ R – Replace $\,$ C – Clean $\,$ L – Lubricate Items with a + sign are requested by owner.

Items marked * should be serviced by an authorised HONDA dealer, unless the owner has proper tools and is mechanically proficient. Other maintenance items may be serviced by the owner. ** Initial service period 200 miles. *** Initial service period 1,500 miles.

NOTE: When for example, doing the 3,000 mile service, the 1,500 mile & 500 mile services must also be done.

Date of Issue: JUNE 20, 1977 © HONDA MOTOR CO. LTD., 1977